

TOOLS REQUIRED

Wrench or Hexagonal Socket Wrench

PARTS:

- ① (2) Pan Slide Frames
- ② (4) Crossbars
- ③ (8) Gasket
- ④ (8) M8*40 Bolts
- ⑤ (4) Foot Plugs
- ⑥ (4) Supporting Feet



①



②



③



④



⑤



⑥



Assembly Guide

The assembly area should be clean and level surface.

Please wear gloves during assembling and handle with care.

1. Insert the crossbars into the top holes of the rack frames. Attach gasket to the outside of the rack frames using the bolts. Repeat the process for the other side.
2. Please repeat step 1 for bottom installation.
3. Insert foot plug into the bottom.
4. Insert the supporting foot into the foot plug.
5. Tighten all bolts with wrench. Now you can put the tray on.

