


ADS-150 EXPLODED DIAGRAM



ADS-150 PARTS LIST

Item	FHE Part Code	Description	Qty
1*	B.7.ZW.150X.010	Front Glass	1
2	B.2.ZW.150R.040	Top Cover	1
3*	B.2.HW.115.220	Handle	4
4	B.2.ZW.150R.070	Upper Door Frame	2
5*	B.3.ZW.150R.010	Door Glass	2
6	B.2.HW.115.050	Door Hinge Latch A	2
7*	B.2.HW.115.210	Door Hinge	2
8	B.2.ZW.150R.080	Lower Door Frame	2
9	B.3.ZW.100R.010	Foot Pad	4
10	B.2.CS.104.100	Nut Trim	8
11	B.3.CS.104.040	Decorative Nut Gasket	8
12	B.3.CS.104.050	Nut Large Gasket	14
13*	B.7.ZW.100X.010	Left Side Glass	1
14*	B.9.10.002	Top Solid Wood Shelf	3
15*	B.2.ZW.100R.100	Small Grille Tray	3
16*	B.2.ZW.150R.050(A1)	Shelf	1
17	B.2.ZW.100R.160	Left Shelf Support	1
18	B.2.ZW.100R.110	Door Hinge Latch B(Left)	2
19	B.2.ZW.100R.010(A1)	Left Pillar	1
20*	B.9.10.001	Bottom Solid Wood Shelf	3
21*	B.2.ZW.100R.090	Large Grille Tray	3
22	B.2.ZW.150R.030	Curved Glass Backplate	1
23*	B.3.HW.120.080	Upper Side Seal Strip	2
24	B.2.ZW.150R.020	Curved Glass Front Plate	1
25*	B.5.07.006	Switch	1
26	B.2.ZW.150R.010	Frame	1
27	B.2.ZW.150R.060	Base Plate	1
28	B.3.CL.58.520	White Adjusting Foot (Japan only)	4

ADS-150 EXPLODED DIAGRAM

Item	FHE Part Code	Description	Qty
29*	B.5.16.069	LED Light 2700K	2
30	B.2.ZW.100R.130	Door Hinge Latch A(Right)	2
31	B.2.ZW.100R.170	Right Shelf Support	1
32	B.2.ZW.100R.120	Door Hinge Latch B(Right)	2
33	B.2.ZW.100R.020(A1)	Right Pillar	1
34*	B.7.ZW.100X.020	Right Side Glass	1
35	B.5.06.001	Power Cord	1
36*	B.7.ZW.150X.020	Top Glass	1
37	B.3.ZW.150X.010	Upper Pillar	1
	ADS-150-CGD	Complete Glass Door	

*Wearable parts