


DH-310E EXPLODED DIAGRAM



DH-310E PARTS LIST

Item	FHE Part Code	Description	Qty	Remark
1		Main Frame	1	
2	70100500164	Power cord 3 x 1mm ²	1	
3	802001008012	Dummy Plate 20201016008	1	
4	20201016011	Mounting Plate for Heating Element	1	
5*	PW-RT/380/TG-24	Lamp Holder 301130053/ 70101300537/DH-310-05	2	
6*	DH-310-08	Halogen Lighting Lamp 50W 301130047/70101300473	2	
7*	DH-310 ELEMENT	Electric Heating Tube 110V 450W 301040084/70100400846	2	
8		Set Screw for Heating Element M5×20	17	
9	AT936-19	Rubber Foot 302090027/70200900273/DH-310-09	4	
10		Set Screw for Rubber Foot M6×20	4	
11	70201200173	Food Pan 1/1×2.5"	1	
12	802001008012	Separation Plate 20201016010/DH-310-20	1	
13-1*	DH-310-13	Control Switch 301080014/70100800146	2	
13-2*	301150044	Switch Rubber Case for ON/OFF Switch 70101500446	2	
14	70301238328	Facial Panel 303120369	1	
15		Controlling Plate	1	

*Wearable parts

FHE After Sales Service & Support (AU)
 Phone: 1300887055
 Spares Email: spares@fedservices.com.au

FHE After Sales Service & Support (NZ)
 Phone: 09 415 6471
 Service Email: service@fedproducts.co.nz